

TANGO Desktop 2HE neo

Comparison of the new equipment options with their preceding models.

**Find
your
TANGO!**

TANGO Desktop 2HE neo

Order No.	Axes	TANGO 1 DT 00-76-150-1801	TANGO 2 DT 00-76-150-1802	TANGO 3 DT 00-76-150-1803	TANGO 4 DT 00-76-150-1804	AUX/IO (without Trigger/ Snapshot) 00-76-801-9803	AUX/IO (with Trigger/ Snapshot) 00-76-801-0802	Encoder Interface 00-76-650-0802
00-4076-0000-2200	1 (Z)	●	○	○	○	●	○	○
00-4076-0000-2202	2 (XY)	○	●	○	○	●	○	○
00-4076-0000-2203	3 (XYZ)	○	○	●	○	●	○	○
00-4076-0000-2204	4 (XYZA)	○	○	○	●	●	○	○

TANGO Desktop 2HE neo with Encoder Interface

Order No.	Axes	TANGO 1 DT 00-76-150-1801	TANGO 2 DT 00-76-150-1802	TANGO 3 DT 00-76-150-1803	TANGO 4 DT 00-76-150-1804	AUX/IO (without Trigger/ Snapshot) 00-76-801-9803	AUX/IO (with Trigger/ Snapshot) 00-76-801-0802	Encoder Interface 00-76-650-0802
00-4076-0000-2250	1 (Z)	●	○	○	○	●	○	●
00-4076-0000-2252	2 (XY)	○	●	○	○	●	○	●
00-4076-0000-2253	3 (XYZ)	○	○	●	○	●	○	●
00-4076-0000-2254	4 (XYZA)	○	○	○	●	●	○	●

TANGO Desktop 2HE neo with Trigger/Snapshot

Order No.	Axes	TANGO 1 DT 00-76-150-1801	TANGO 2 DT 00-76-150-1802	TANGO 3 DT 00-76-150-1803	TANGO 4 DT 00-76-150-1804	AUX/IO (without Trigger/ Snapshot) 00-76-801-9803	AUX/IO (with Trigger/ Snapshot) 00-76-801-0802	Encoder Interface 00-76-650-0802
00-4076-0100-2200	1 (Z)	●	○	○	○	○	●	○
00-4076-0100-2202	2 (XY)	○	●	○	○	○	●	○
00-4076-0100-2203	3 (XYZ)	○	○	●	○	○	●	○
00-4076-0100-2204	4 (XYZA)	○	○	○	●	○	●	○

TANGO Desktop 2HE neo with Encoder Interface and Trigger/Snapshot

Order No.	Axes	TANGO 1 DT 00-76-150-1801	TANGO 2 DT 00-76-150-1802	TANGO 3 DT 00-76-150-1803	TANGO 4 DT 00-76-150-1804	AUX/IO (without Trigger/ Snapshot) 00-76-801-9803	AUX/IO (with Trigger/ Snapshot) 00-76-801-0802	Encoder Interface 00-76-650-0802
00-4076-0100-2250	1 (Z)	●	○	○	○	○	●	●
00-4076-0100-2252	2 (XY)	○	●	○	○	○	●	●
00-4076-0100-2253	3 (XYZ)	○	○	●	○	○	●	●
00-4076-0100-2254	4 (XYZA)	○	○	○	●	○	●	●